



S-622CS HH Control Layout



Selector Functions

Normal Mode

(Tone Knob Pushed Down)



Coil Tap Mode

(Tone Knob Pushed Up)

