


S-622CS HSH Control Layout




Selector Functions

← Neck Position • Bridge Position →

Normal Mode

(Tone Knob Pushed Down)



Coil Tap Mode

(Tone Knob Pushed Up)

